

# Lucas Equipment Specifications

## Austin Healey : BN1 – BJ8

Lucas Equipment Specification 100	Page 2
Lucas Equipment Specification 100-6	3
Lucas Equipment Specification 3000 MkI	4
Lucas Equipment Specification 3000 MkII	5
Lucas Equipment Specification 3000 MkII BJ7	6
Lucas Equipment Specification 3000 MkIII	7



Prepared by J. Scott Morris [ [jstmorris@yahoo.com](mailto:jstmorris@yahoo.com) ] 2008-05-03

*C:\British Cars\Austin Healey\Tech\04 - Identification\Specifications\Lucas Equipment Specifications-Big Healey.doc*



AUSTIN Austin-Healey '100' and '100M' 1954-56

Unit	Year	Part No.	Unit	Year	Part No.	Unit	Year	Part No.
Battery .. .. .	1954-55	SLG11E	LAMPS—continued			Windshield wipers		
Coil, ignition .. .. .	1956	SLT11E	Head, Export France ..	1954-55	*51341A	Motor .. .. .	1954	75150A
Control box .. .. .	1954-55	*45012A/D	Head, Export U.S.A. ..	1956	*51341B/E	" .. .. .	1955	75144A
Distributor (100) ..	1956	*45054D/E	Number plate illumination	1954-56	51509A/H	" .. .. .	1956	*75214A
" (100M) ..	1954-55	*37139D/E	Side and flasher .. .. .	1954-55	53093E	Wheelbox .. .. .	1954-55	72629D
" .. .. .	1956	37183A/H	Stop tail .. .. .	1954-55	*52162B/D	" .. .. .	1956	*72674A
" .. .. .	1954-56	*40320A/B	Reflex reflector .. .. .	1956	52240D	Crosshead and rack assy.		
" .. .. .	1956	40495A	Panel light bulb holder ..	1954-56	53178B/F	Cut to 30 <sup>5</sup> / <sub>8</sub> " .. .. .	1954-55	738764
" .. .. .	Later	*40422B	Starting motor .. .. .	1955	57052A	" .. 31 <sup>33</sup> / <sub>32</sub> " .. .. .	1956	743221
" .. .. .	1956	40520A	Steering column control ..	1956	*57084A	Outer casing		
Flasher unit .. .. .	1954-56	*35003A	" .. .. .	1954	39020B	Motor to wheelbox ..	1954-55	739844
Flasher relay .. .. .	1954-56	33117A	" .. .. .	1954	25521B/D	" .. .. .	1956	743880
Fuse box .. .. .	1954-56	033240	" .. .. .	1954	*32900A/B	Wheelbox to wheelbox	1954-55	*739971
Generator .. .. .	1954	*22456A/B	" .. .. .	1955-56	32918A	" .. .. .	1956	743881
" .. .. .	1955	*22483A	SWITCHES			3" offside wheelbox ..	1954-55	740031
" .. .. .	1956	*22483B	Battery master .. .. .	1954-56	76605A	End tube .. .. .	1956	740746
Horn .. .. .			Dipper .. .. .	1954-56	*31372A	Arm, left hand drive ..	1954-55	*737571
Low note .. .. .	1954-56	*70063A/F	Ignition .. .. .	1954-56	31403A/B	" .. .. .	1956	745083
High note .. .. .	1954-56	*70071A/F	Lighting .. .. .	1954-56	*31432A	Arm, right hand drive ..	1954-55	*737570
LAMPS			Knob .. .. .	—	316129	" .. .. .	1956	745082
Driving (optional) ..	1955-56	55132B	Panel .. .. .	1954-56	*31140A	Blade .. .. .	1954-56	738724
Fog (optional) .. ..	1955-56	55128B	Solenoid, starting motor	1954-56	*76411D/E			
Head, Home			Solenoid operating .. .. .	1954-56	*31318A			
R.H.D., dip left ..	1954-55	51336A	Stop lamp .. .. .	1956	31082E			
" .. .. .	1956	51336B/J	Windshield wiper .. .. .	1954-56	*31431A			
Head, Export			Knob .. .. .	—	317530			
R.H.D., dip left ..	1954-55	51336A	Trafficators .. .. .	1955	54044D			
" .. .. .	1956	51336B/J	Warning lights					
L.H.D., dip right ..	1954	*51337A	Ignition .. .. .	1955	39020A			
" .. .. .	1955	*51337B	" .. .. .	1956	38067A			
" .. .. .	1956	*51337D/E	Bulb holder, flasher .. ..	1956	39020A			
Head, Export Europe			" .. .. .	1956	554734			
(not France) .. .. .	1954-55	51339A	Bulb .. .. .	1955-56	987			
ditto .. .. .	1956	51339B/H						

\* See Supersession Chart

L.H.D. .. Left hand drive R.H.D. .. Right hand drive

Note. Before ordering Steering Column Controls refer to the detailed parts section (P)



# Equipment Specification

# AUSTIN

## AUSTIN Austin-Healey '100 Six' (BN4 and BN6) 1957-59

Battery .. .. .	1957-58	GT9A-3	<b>LAMPS—continued</b>			<b>SWITCHES—continued</b>		
" (alternative, 2 off)	1957-58	SLTW15E	Head, Export Europe			Windshield wiper ..	1957-59	*31431A
" (BN4) .. .. .	1959	BT9A	(except France & Sweden)			Knob .. .. .	—	317530
" (BN6 2 off) ..	1959	SLG11E	Later	1959	58290A	<b>Warning lights</b>		
Bulb holder, panel light ..	1957-59	39007A	Head, Export France ..	1957-59	51958B	Bulb holder, flasher ..	1957-59	39020B
" .. .. .	1957-59	554734	" .. .. . Later	1959	58291A	" .. .. . ignition ..	1957-59	863511
Bulb .. .. .	—	987	Head, Export Sweden ..	1959	58463A	" .. .. . main beam	1957-59	554734
Coil, ignition .. .. .	1957-59	*45054E/K	Head, Export U.S.A. ..	1957-59	51957B/D	Bulb .. .. .	—	987
Control box .. .. .	1957-59	37183H	Number plate illumination	1957-59	53093H	<b>Windshield wipers</b>		
" .. .. . Later	1959	37183K	Side and flasher .. .. .	1957-59	52338A	Motor .. .. .	1957	*75214A
Distributor .. .. .	1957	40532A	Stop tail and flasher ..	1957-59	53564A	" .. .. .	1958-59	75297B/D
" .. .. .	1958-59	*40581A/B	Reflex reflector .. .. .	1957-59	57072B	Wheelbox .. .. .	1957-59	*72674A/B
Flasher unit .. .. .	1957-59	35010A	Starting motor .. .. .	1957-59	25521D	Crosshead and rack assy.		
Flasher relay .. .. .	1957-59	33117A/D	Steering column control ..	1957-59	32984A/B	Cut to 31 <sup>13</sup> / <sub>16</sub> " .. .. .	1957-59	743221
Fuse box .. .. .	1957-59	033240				Outer casing		
Generator .. .. .	1957	*22483A	<b>SWITCHES</b>			Motor to wheelbox ..	1957-59	743880
" .. .. . Later	1957-59	*22483B/D	Battery master .. .. .	1957	76605A	Wheelbox to wheelbox	1957-59	743881
Horn .. .. .			" .. .. .	1958-59	*76604B	End tube .. .. .	1957-59	740746
Low note .. .. .	1957-59	*70063E/F	Dipper .. .. .	1957-58	*31372A	Ferrule, casing retaining	1957-59	740715
High note .. .. .	1957-59	*70071E/F	" .. .. . Later	1958-59	31284A/D	Arm, left hand drive ..	1957-59	745083
<b>LAMPS</b>			Heater .. .. .	1957	*78261B	" .. .. . right hand drive ..	1957-59	745082
Head, Home			Knob .. .. .	—	768473	Blade .. .. .	1957-59	738724
R.H.D., dip left ..	1957-59	51956B/F	Ignition .. .. .	1957-59	31403B/H	<b>Laycock de Normanville</b>		
Head, Export			Lighting .. .. .	1957-59	*31432A/D	<b>overdrive equipment</b>		
R.H.D., dip left ..	1957-59	51956B/F	Knob .. .. .	—	316129	Relay .. .. .	1957-59	33157D
L.H.D., dip right ..	1957-59	*51966B/E	Panel .. .. .	1957-59	31140A/B	Solenoid .. .. .	1957-58	*76510A
Head, Export Europe			Solenoid, starting motor	1957-59	*76411E	" .. .. . Later	1958-59	76515A
(not France) .. ..	1957-59	51959A/E	Rubber boot .. .. .	—	858266	<b>Switches</b>		
			Solenoid operating .. .. .	1957-59	*31318A	Interrupter .. .. .	1957-58	*31077E
			Stop lamp .. .. .	1957-59	31082E/H	Rotary, throttle .. ..	1957-58	31402A/B

\* See Supersession Chart    L.H.D. .. Left hand drive    R.H.D. .. Right hand drive

A30

Note. Before ordering Steering Column Controls refer to the detailed parts section (P)



Equipment Specification

AUSTIN

AUSTIN Austin-Healey '3000' 1959-60

Battery (2-seater) ..	1959-60	SLG11E	LAMPS— <i>continued</i>			SWITCHES— <i>continued</i>		
" (4-seater) ..	1959-60	BT9A	Head, Export France ..	1959-60	58291A/B	Solenoid, starting motor	1959-60	*76411E
Bulb holder, panel light ..	1959-60	554734	Head, Export Sweden ..	1959-60	58463A/B	Solenoid operating ..	1959-60	*31318A
" " " " " ..	1959-60	39007A	Head, Export U.S.A. ..	1959-60	58569A	Stop lamp ..	1959-60	31082H/J
" " " " " ..	—	987	" " " " Later	1960	58626A	Windshield wiper ..	1959	*31431A
Coil, ignition ..	1959-60	45102B/E	Number plate illumination	1959-60	53093H/J	" " " " ..	1960	*31419A
Control box ..	1959-60	37183K	ditto (Switzerland)	1960	53905A	Knob ..	1959-60	317530
Distributor ..	1959-60	40662A/D	Side and flasher ..	1959-60	52338A/D	Warning lights		
Flasher unit ..	1959-60	35010A	Stop tail and flasher ..	1959-60	53564A/B	Bulb holder		
Flasher relay ..	1959-60	33117D	Reflex reflector ..	1959-60	57072B	Flasher ..	1959-60	38067A
Fuse box ..	1959-60	033240	Sleeve, Lucar connector			Ignition ..	1959-60	863511
Generator ..	1959-60	22530A	14 amp. ..	1959-60	54190042	Main beam ..	1959-60	554734
Horn			35 amp. ..	1959-60	54190043	Bulb ..	—	987
Low note ..	1959-60	*70063F	Starting motor ..	1959-60	25521D	Windshield wipers		
High note ..	1959-60	*70071F	Steering column control			Motor ..	1959-60	75297E
LAMPS			Fixed ..	1959-60	33517A/F	Wheelbox ..	1959-60	*72674A
Head, Home			Adjustable ..	1959-60	32984A/B	Crosshead and rack assy.		
R.H.D., dip left ..	1959-60	51956D/F	SWITCHES			Cut to 31 <sup>13</sup> / <sub>16</sub> " ..	1959-60	743221
Head, Export			Battery master ..	1959-60	*76604B	Outer casing		
R.H.D., dip left ..	1959-60	51956F	Dipper ..	1959-60	31284D	Motor to wheelbox ..	1959-60	743880
L.H.D., dip right ..	1959-60	*51966E	Ignition ..	1959-60	31403H	Wheelbox to wheelbox	1959-60	743881
Head, Export Europe			Lighting ..	1959-60	*31432D	End tube ..	1959-60	740746
(except France & Sweden)	1959-60	58290A/B	Knob ..	—	316129	Arm, left hand drive ..	1959-60	745083
			Panel ..	1959-60	31140B	" right hand drive ..	1959-60	745082
						Blade ..	1959-60	738724

\* See Supersession Chart

L.H.D. .. Left hand drive R.H.D. .. Right hand drive

A30

Note. Before ordering Steering Column Controls refer to the detailed parts section (P)



**EQUIPMENT SPECIFICATIONS**

**Austin-Healey '3000' and '3000' Mk.II (BN7, 2-seater and BT7, 4-seater)**

UNIT	Model	Part No.	UNIT	Model	Part No.	UNIT	Model	Part No.
Ammeter (special orders) ...	CZU69	362B1A	Flasher relay ...	DB10	33117D	Lamps, Head—continued		
Battery (4-seater) ...	BT7A	—	Fuse box ...	SF6	033240	Export U.S.A. ...	F700	*58496B
Battery (2-seater, 2 off) ...	SLG11E	—	Generator ...	C45PV-6	22530A/B	Number plate ...	467	(58569)
Bulb holder, panel light ...	—	554734	Horn—High note ...	HF174B	*70071F	Switzerland) ...	469	53836F
Bulb holder, panel light ...	—	39007A	Low note ...	HF174B	(069474)	Side and flasher ...	594	53905A
Bulb ...	—	987	Lamps:		*70063F	Scop tail and flasher ...	594	52336B
Coil, ignition ...	HA12	45102E	Head		(069448)	Reflex reflector ...	RER25	57125A
Connector, Lucas, female	—	—	Right hand drive, dip left ...	F700	51956F	Reflex reflector (Export	RER14	57083A
14 amp. ...	—	54942078	Left hand drive, dip right ...	F700	*51956D/E	Switzerland) ...	—	54190042
35 amp. ...	—	54942079	Export Europe (except	F700	58290B	14 amp. ...	—	54190043
14 amp. (double) ...	—	54942747	France and Sweden) ...	F700	58291B	35 amp. ...	—	54190119
Control box ...	RB106-2	37183M	Export France ...	F700	58463B	14 amp. (double) ...	—	
Distributor ...	DM6	40642D	Export Sweden ...	F700	—	Windshield wipers—continued		
Flasher unit ...	FL5	35010A	Switches—continued			Outer casing, motor to wheel-		
Starting motor ...	M418G	25521D	Stop lamp ...	HL2	31082J	box ...	—	743880
Steering column control	CCI	133517E	Windshield wiper ...	PS7	*31431A	Outer casing, wheelbox to	—	743881
Steering column control	CCI	132984B	Knob ...	—	(31431)	wheelbox ...	—	740746
(adjustable, alternative)	CCI	33105B	Warning lights:		317530	Outer casing, short wheelbox	—	745092
Stator tube ...	—	—	Flasher ...	WL11	38067A	Arm, right hand drive ...	—	745083
Switches:			Bulb holder, ignition ...	—	863511	Arm, left hand drive ...	—	738724
Battery maker ...	ST330	*76604B	Bulb ...	—	982	Blade ...	—	
Dipper ...	ES22-1	31284D	Bulb holder, main beam ...	—	554734	LAYCOCK DE NORMANVILLE		
Ignition ...	S45	31403M	Bulb ...	—	987	OVERDRIVE		
Lighting ...	PPG1	*31432E	Windshield wipers:			Interrupter switch ...	SS10	31849A
Knob ...	—	(31126)	Motor ...	DR2	75297E/F	Rosary throttle switch ...	RT51	31402B
Panel ...	10A	31140B	Wheelbox ...	—	72744A	Transmission gear solenoid ...	115	76525A
Solenoid operating ...	SS5	*31318A	Crosshead and rack (cut to	—	743221	Overdrive relay ...	SB40-1	33157D
Solenoid, starting motor ...	ST950	478411E	3111) ...	—				
		(76464)						

\* When ordering, quote part number shown in brackets    † Complete control serviced by Vehicle Manufacturer    ‡ Serviced by C.A.V.    continued





EQUIPMENT SPECIFICATIONS

Austin-Healey '3000' Convertible (BJ7)

Ammeter (special orders) ...	CZU60	36281A	Lamps— <i>continued</i>			Switches— <i>continued</i>		
Battery ...	BT9A	24016417	Side and flasher ...	594	52338B	Stop lamp ...	HL2	31082J
Dry charged (Export) ...	BTZ9A	24016427	Later ...	594	*52607A	Stop lamp (Servo brakes) ...	HL2	31440E
Bulb holder, panel light... ..	—	554734	Side		(52338)	Windshield wiper ...	PS7	*31431A
Bulb ...	—	987	Export Germany and Sweden	594	52391B	Knob ...	—	(31434)
Bulb holder, panel light... ..	—	39007A	Later ...	594	*52608A	Warning lights:		317530
Bulb ...	—	987	Stop tail and flasher ...	594	(52391)	Flasher ...	WL13	*319083
Cable sundries (see page 25) ...			Later ...	594	53564D			(83067)
Coil, ignition ...	HA12	45102H	Reflex reflector ...	RER25	*54140A	Bulb holder, ignition ...	—	863511
Control box ...	RB106-2	37183M	Export Germany and Sweden	RER14	(53564)	Bulb ...	—	987
Distributor ...	DM6	40662D	Relay, flasher ...	DB10	57125A	Bulb holder, main beam	—	554734
Later ...	25D6	40920A/B	Starting motor ...	M418G	57083A	Bulb ...	—	987
Flasher unit ...	FL5	35010A	Steering column control		33117D	Windshield wipers:		
Fuse box ...	SF6	54038027	Adjustable ...	CC1	25578A	Motor ...	DR2	75297F
Generator ...	C45PV-6	22530B	Fixed ...	CC1	†32984B	Wheelbox ...	—	72744B
Horn—High note ...	9H	54068008	Suppressor (United Kingdom and		†33517F	Rack (cut to 31 1/2") ...	—	743221
Low note ...	9H	54068009	Germany) ...	WS5		Outer casing		
LAMPS:			Battery master ...	ST330	78106A	Motor to wheelbox ...	—	743880
Flasher, front			SWITCHES:			Wheelbox to wheelbox ...	—	743881
Export Germany and Sweden	594	52337B	Dipper ...	FS22-1	*76604B	Short, wheelbox ...	—	740746
Later ...	594	*52609A	Ignition ...	S45	(76605)	Ferrule, outer casing retaining	—	740715
Head			Lighting ...	PPG1	31284D	Arm, right hand drive ...	—	54712044
Right hand drive, dip left ...	F700	51956F/H	Knob ...	—	31403H	Arm, left hand drive ...	—	54712045
Left hand drive, dip right ...	F700	*51966E/F	Panel ...	10	*31432F	Blade ...	—	54711613
Export U.S.A. ...	F700	(51957)	Solenoid, starting motor ...	2ST	(31126)	LAYCOCK DE NORMANVILLE		
Export Europe (except coun-		*58626B	Solenoid operating ...	SS5	316129	OVERDRIVE ...		
tries stated) ...	F700	(58776)			31140B	Solenoid ...	IIS	76525E
Export France ...	F700	58290D			*76445E	Interrupter switch ...	SS10	31849B
Export Sweden ...	F700	58291D			(76464)	Rotary throttle switch ...	RTS1	31402B
Number plate	467	58463D			*31318B	Relay ...	SB40	33157D
		53836F			(31363)			

\* When ordering, quote part number shown in brackets

† Complete control serviced by Vehicle Manufacturer



**EQUIPMENT SPECIFICATIONS**

**AUSTIN-HEALEY '3000' Mk. III (BJ8)**

UNIT	Model	Part No.	UNIT	Model	Part No.	UNIT	Model	Part No.
Battery ... ..	BT9A	24016417	Lamps— <i>continued</i>			Warning lights— <i>continued</i>		
Dry charged (Export) ...	BTZ9A	24016427	Number plate ... ..	467	53836F	Bulb holder (flasher) ... ..	—	863511
Bulb holder, panel light... ..	—	554734	Number plate (Germany) ...	467-2	54352A	Bulb ... ..	—	987
Bulb ... ..	—	987	Side ... ..	691	52750E	Bulb holder (ignition and main		
Bulb holder, speedometer ...	—	54944812	Export Germany ... ..	594	54057258	beam) ... ..	—	319408
Bulb ... ..	—	987	Stop tail ... ..	692	*53955D	Bulb ... ..	—	987
Cable sundries (see page 32)			Export Germany ... ..	692	(54296)	Bulb holder (oil) ... ..	—	54944812
Coil, ignition ... ..	HA12	*45102H	Reflex reflector ... ..	RER14	54335A/B	Bulb ... ..	—	987
		(45132)	Starting motor ... ..	M418G	57083A			
Control box ... ..	RB340	37331H	Steering column control		25578B	Windshield wipers:		
Distributor ... ..	25D6	40966E	Adjustable ... ..	CCI	†32984B	Motor ... ..	DR3A	75456B/D
Flasher unit ... ..	FL5	35020A	Fixed ... ..	CCI	†33517F	Wheelbox ... ..	—	72744A
Flasher unit (Germany) ...	FL5	35040A	Suppressor (United Kingdom and	WS5	78106A	Rack (cut to 31 $\frac{1}{2}$ " ) ... ..	—	743221
Fuse box ... ..	4FJ	54038033	Germany) ... ..			Outer casing		
Generator ... ..	C42	22900J				Motor to wheelbox ... ..	—	54716689
Horn—High note ... ..	9H	54068086				Wheelbox to wheelbox ... ..	—	*743881
Low note ... ..	9H	54068087						(745043)
						Short, wheelbox ... ..	—	740746
						Arm, right hand drive ... ..	—	54712044
						Arm, left hand drive ... ..	—	54712045
						Blade ... ..	—	54711613
LAMPS			SWITCHES			OVERDRIVE EQUIPMENT		
Flasher, front and rear ...	691	52751D	Auxiliary or overdrive ...	65SA	31828D	Solenoid ... ..	IIS	76525F/H
Flasher, front and rear			Battery master ... ..	ST330	*76604B	Interrupter switch ... ..	SS10	31849B
(Germany) ... ..	691	52760B			(76605)	Rotary throttle switch ... ..	RTS1	31402B
Flasher, front (Italy) ... ..	691	52761A	Dipper ... ..	103SA	34536E	Relay ... ..	6RA	33213E
Head			Ignition and starter ... ..	47SA	31973J			
Right hand drive, dip left ...	F700	58811D	Lighting ... ..	57SA	31837E			
Left hand drive, dip right ...	F700	58817B	Panel ... ..	65SA	31828D			
Export North America ... ..	F700	59191B	Solenoid, starting motor ...	2ST	*76471H			
Export Europe (except coun-			Stop lamp ... ..	HL2	(76445)			
tries stated) ... ..	F700	58814E	Windshield wiper ... ..	57SA	*31882B			
Export France ... ..	F700	58815E			(53033360)			
Export Sweden ... ..	F700	59702A	Warning lights:		34426E			
Rim ... ..	—	†556234	Cover and window (flasher) ...	—				
Gasket ... ..	—	‡54521487	Shade (flasher)... ..	—				

\* When ordering, quote part number shown in brackets † Complete control serviced by Vehicle Manufacturer ‡ Order separately

**Brake and Clutch Equipment**  
(Serviced by Girling Ltd.— see page 22)