



INSTALL GROOVE (A) FIRST, THEN EASE IN THE GROOVE LIP ON OTHER SIDE WITH A BLUNT SCREW DRIVER. LUBRICATE WITH MASTER (R) SILICONE LUBRICANT (SEAL AND METAL) CUT OFF TO SIZE AT EACH END AFTER INSTALLING

*British Car Specialists*  
 2060 N. Wilson Way  
 Stockton, CA 95205-3126